Panasonic DECT



Pairing and Activation Guide

Equipment: Panasonic DECT Base Kit KX-TGP600

Panasonic DECT Base Activation

To activate this base unit, turn on the Panasonic DECT handset the was included with the base unit. The Initial handset in the KX-TGP600 Kit box and the base are paired together at the factory. All other handsets (up to 8 grand total per base) need to be paired to the base and are activated individually

Activating the Base (which activates the initial handset automatically)

- 1. Type any number on the handset and press the green call button.
- 2. The announcement will request you enter the Activation Code for the base.
- 3. Enter the Activation Code you received, similar to that shown below.

 Base Activation Code (Example) 2931 4692 8161

Panasonic DECT Handset Registering (Pairing and Activation):

[This pairs the handset to the base that has already been activated and activates the handsets]

- 1. Preparing the Base Unit to Register (pair and activate) a handset:
 - a. Press and hold the handset locator button for about 3 seconds.

The STATUS indicator on the base unit will flash red (slow flashing).

- 2. Registering (Pairing and Activating) an Unregistered handset/desk phone:
 - [When adding a new handset/desk phone, refer to images below]
 - a. In standby mode, press and hold OK until displaying "Please Wait \dots "
 - b. After Registered is displayed on the LCD, the registration is completed.




Press and hold "OK soft key"

Approximately for 6 seconds







8x8 Account Manager view of Panasonic DECT Base and Endpoint Activation.